



# XEROX 820 PROCESSOR INSTALLATION FOR 8" DISKS




## 1 TAKE ALL UNITS OUT OF THE BOXES

Take the units out of the boxes and remove all the packing material from around the units. You may throw the packaging materials away. Or, you may save the materials for moving the system in the future.




## 3 PREPARE TO PLUG THE DISK DRIVES INTO THE BACK OF THE SCREEN:

Set the disk drives and the screen on your desk or table. Locate the plug on the disk drives and look at the end. Notice that the ring around the pins is larger on one side. Turn the plug so that the larger side is up.



## 2 YOU SHOULD HAVE:

- o Screen, Keyboard, Disk Drives and power cord
- o A screwdriver
- o A disk marked Diagnostic Exerciser
- o At least one instruction manual
- o If you have the Diablo 630 printer, you should also have two printer cords, a print wheel and a ribbon




## 4 CONNECT THE DISK DRIVES AND SCREEN:

Holding the disk drive plug so that the larger side of the pin ring is up, plug it into the outlet marked "DISK DRIVES" on the left side of the back of the screen. Use a screwdriver to tighten the screws on both sides of the plug. (Be careful not to over tighten the screws). Plug the screen power cord into the back of the disk drives.


610P70655

OVER ➤




## 5 PLUG THE KEYBOARD INTO THE BACK OF THE SCREEN:

Look at the end of the keyboard plug. Notice that the ring around the pins is larger on one side. Turn the pin so that the larger side is up, then plug it into the outlet marked "KEYBOARD" on the back of the screen. Tighten the screws on the plug.




## 7 PLUG THE PRINTER INTO THE BACK OF THE SCREEN:

The Diablo 630 printer has two cords. The cord with the larger plug goes to the screen; the other one goes to a power outlet. Look at the end of the larger plug and turn it so the larger end of the pin ring is up. Then plug it into the outlet on the screen marked "PRINTER". Tighten the plug screws.



## 6 SET UP YOUR PRINTER:

If you have a Diablo 630 printer, shown above, follow the directions in the SYSTEM COMPONENTS section of the 820 3-ring binder manual. If you have a different printer, follow the directions that came with your printer. Then continue with step 7 below.



## 8 CONNECT THE DISK DRIVE POWER CORD AND CHECK THE SYSTEM OUT

Plug the power cord into the back of the disk drives, then into a power outlet. Plug your 630 printer into a power outlet, if you have not done so. Then follow the directions in the DIAGNOSTIC section of your 820 3-ring binder manual to be sure your 820 is in proper working order.